



- The vehicle identification number is punch-marked on the plate, which is attached in the position as illustrated.

The vehicle identification number consists of a 17-digit set of alphanumeric characters. Each digit represents the following specifications.

J L 6 A A D 1 S ■ 5 K ■ ■ ■ ■ ■ ■

(1) (2) (3) (4) (5) (6) (7) (8) (9) (10) (11) (12)

- | | |
|---|---|
| (1) Country | J: Japan |
| (2) Make | L: Mitsubishi Fuso |
| (3) Type | 6: Incomplete vehicle |
| (4) Gross vehicle weight / Brake system | A: 10,001 to 14,000 lbs. / Hydraulic |
| | B: 14,001 to 16,000 lbs. / Hydraulic |
| | C: 16,001 to 19,500 lbs. / Hydraulic |
| (5) Line | A: FE83D |
| | B: FE84D |
| | C: FE85D |
| (6) Series (Wheel base) | D: 2.9 to 3.19 m (9.51 to 10.46 ft.) |
| | E: 3.2 to 3.49 m (10.49 to 11.44 ft.) |
| (7) Cab chassis type | 1: Chassis cab |
| (8) Engine | S: 4.899 L Diesel turbo charged and charge air cooled |
| (9) Check digit | |
| (10) Model year | 5: 2005 |
| (11) Plant | K: Kawasaki |
| (12) Plant sequential number | |